

DTIC FILE COPY



AD-A224 241

ONR CONTRACT

N00014-87-J-1275

PULSED PLASMA PREPARATION  
FOR LMIR MATERIALS

FINAL REPORT

DTIC  
S ELECTE D  
JUL 05 1990  
E

DISTRIBUTION STATEMENT A

Approved for public release;  
Distribution Unlimited

STC TECHNOLOGY LTD

①

ONR CONTRACT

N00014-87-J-1275

PULSED PLASMA PREPARATION  
FOR LWIR MATERIALS

FINAL REPORT



Accession For	
NTIS GRA&I	<input checked="" type="checkbox"/>
DTIC TAB	<input checked="" type="checkbox"/>
Unannounced	<input type="checkbox"/>
Justification	
By	
Distribution/	
Availability Codes	
Avail and/or	
Dist	Special
A-1	

DTIC  
JUL 05 1990  
D

DISTRIBUTION STATEMENT A  
Approved for public release;  
Distribution Unlimited

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE

## REPORT DOCUMENTATION PAGE

1a. REPORT SECURITY CLASSIFICATION UNCLASSIFIED/UNLIMITED			1b. RESTRICTIVE MARKINGS NONE	
2a. SECURITY CLASSIFICATION AUTHORITY			3. DISTRIBUTION/AVAILABILITY OF REPORT UNRESTRICTED	
2b. DECLASSIFICATION/DOWNGRADING SCHEDULE				
4. PERFORMING ORGANIZATION REPORT NUMBER(S) IR/105/1990/1494			5. MONITORING ORGANIZATION REPORT NUMBER(S) STL-No. 03	
6a. NAME OF PERFORMING ORGANIZATION STC TECHNOLOGY LTD	6b. OFFICE SYMBOL (if applicable) STL	7a. NAME OF MONITORING ORGANIZATION OFFICE OF NAVAL RESEARCH DR. R. SCHWARTZ.		
6c. ADDRESS (City, State, and ZIP Code) LONDON ROAD HARLOW, ESSEX CM17 9NA ENGLAND		7b. ADDRESS (City, State, and ZIP Code) CODE 38504 NAVAL WEAPONS CENTER CHINA LAKE CA 93555-6001		
8a. NAME OF FUNDING/SPONSORING ORGANIZATION OFFICE OF NAVAL RESEARCH	8b. OFFICE SYMBOL (if applicable)	9. PROCUREMENT INSTRUMENT IDENTIFICATION NUMBER N00014-87-J-1275		
8c. ADDRESS (City, State, and ZIP Code) 800 N. QUINCY STREET ARLINGTON VA 22217-500 DR. R. POHANKA		10. SOURCE OF FUNDING NUMBERS PROGRAM ELEMENT NO. PROJECT NO. TASK NO. WORK UNIT ACCESSION NO. N6927 431-A-018		
11. TITLE (Include Security Classification) PULSED PLASMA DEPOSITION FOR LWIR MATERIALS				
12. PERSONAL AUTHOR(S) G. A. SCARSBROOK				
13a. TYPE OF REPORT TECHNICAL - FINAL	13b. TIME COVERED FROM 1987/10 TO 1989/12	14. DATE OF REPORT (Year, Month, Day) 1990/06/18	15. PAGE COUNT 38 + 8	
16. SUPPLEMENTARY NOTATION				
17. COSATI CODES FIELD GROUP SUB-GROUP			18. SUBJECT TERMS (Continue on reverse if necessary and identify by block number) PULSED PLASMA, THIN FILM DEPOSITION, COMPLETE GAS DISSOCIATION, LONG WAVELENGTH, INFRA-RED, AMORPHOUS SUPER PHOSPHIDES, GeP, GaP, ZnP, PHOSPHINE SAFETY ASPECTS.	
19. ABSTRACT (Continue on reverse if necessary and identify by block number) <i>19</i> The objective of this programme was to apply the capabilities of the novel STL pulsed plasma process to the preparation and screening of new infra-red materials. The area of specific interest is transmission window materials for the far infra-red (8-12 micron), which perform better than ZnS in at least one respect, without any trade-off in other properties. Eight binary phosphides, novel in both composition and structure, have been investigated for use in IR applications. Excluding cadmium phosphide, in which the band gap was too small, all the phosphides are harder than ZnS. In addition, most are IR transparent in the regions of interest, though hydrogen inclusion tends to occur in those phosphides with the lighter cations (causing absorption near 12 micron) and silicon and aluminium phosphides exhibit absorption. Aluminium phosphides have for the first time been made stable, at least at the higher phosphorus contents, and addition of zinc to silicon phosphide has demonstrated the potential of ternary additions in beneficially modifying absorption characteristics and mechanical properties. In view of the latter data, the ternary zinc germanium phosphide offers great potential. This ternary is expected to be harder than either binary, with a larger band gap, and any weak absorptions beyond 12 micron are expected to move further away. Gallium phosphides are also still of interest, but are considered of lower priority.				
20. DISTRIBUTION/AVAILABILITY OF ABSTRACT <input type="checkbox"/> UNCLASSIFIED/UNLIMITED <input type="checkbox"/> SAME AS RPT. <input type="checkbox"/> DTIC USERS			21. ABSTRACT SECURITY CLASSIFICATION UNCLASSIFIED/UNLIMITED	
22a. NAME OF RESPONSIBLE INDIVIDUAL DR. R. W. SCHWARTZ			22b. TELEPHONE (Include Area Code)	22c. OFFICE SYMBOL

DD FORM 1473, 84 MAR

83 APR edition may be used until exhausted.  
All other editions are obsolete.SECURITY CLASSIFICATION OF THIS PAGE  
UNCLASSIFIED

# DISTRIBUTION LIST

Dr W Rhodes	GTE Laboratories, Waltham
Mr D Roy	Coors Porcelain Co, Golden
Dr J Savage	Royal Signals & Radar Establishment
Dr I G Talmy	Naval Surface Weapons Center
Defense Documentation Center	
Dr R Pohanka	Office of Naval Research
Mr H Guard	Office of Naval Research
Mr D Nelson	Office of Naval Research
L Slotter	Naval Air Systems Command
Defense Metals & Ceramic Info	
Dr R W Schwartz	Naval Weapons Center
B Wilcox	Materials Sci Office
Metal & Ceramics Prg	Army Research Office
Code AX	Commandant of the Marine Corps
Elec & Mats Sci Dir	Air Force Off of Sci Res/NE
Code 0712	Office of Naval Technology
Code 0725	Office of Naval Technology
Dr A Adler	General Research Int. Santa Barbara
Dr M Akinc	Iowa State University
Dr H E Bennett	Naval Weapons Center
Dr S Block	National Bureau of Standards
Dr J K Burdett	University of Chicago
Dr M A Cappelli	Stanford University, Stanford
Dr B Dunn	University of California, Los Angeles
Dr G Geoffroy	Pennsylvania State University
Dr A Harker	Rockwell Int'l Science Center
Dr D C Harris	Naval Weapons Center
Mr R A Heinecke	STC Technology Ltd
Dr C E Johnson	Naval Weapons Centre, China Lake
Dr L C Klein	Rutgers University
Dr J J Mecholsky, Jr.	Pennsylvania State University
Dr R Messier	Pennsylvania State University
Dr G Messing	Pennsylvania State University
Dr P E D Morgan	Rockwell Int'l Sci Center
Dr C Pantano	Pennsylvania State University
Dr R Raj	Cornell University
Dr R Roy	Pennsylvania State University
Dr A Stacy	University of California, Berkeley
Dr R Tustison	Raytheon Company, Lexington
Dr T A VanDerah	Naval Weapons Center, China Lake
Dr W B White	Pennsylvania State University
Dr A Wold	Brown University, Providence
Dr C Blackmon	Naval Surface Weapons Center
Dr J A Cox	Honeywell Systems & Res. Minneapolis
Dr P Kloczek	Texas Instruments, Dallas
Dr D N Lewis	Naval Research Lab
Dr S Musikant	General Electric Co, Philadelphia
Dr D Perry	US Army Missile Cmd
Dr W Pittman	Redstone Arsenal, Huntsville
Dr A H Guenther	AFWL/CCN, Kirtland AFB
Dr V Donlan	USAF EAORD, London
Mr S Warren	STC Components, Harlow

0409H

NWC Contract N00014-87-J-1275  
PULSED PLASMA PREPARATION FOR LW-IR MATERIALS

SUMMARY

The objective of this programme was to apply the capabilities of the novel STL pulsed plasma process to the preparation and screening of new infra-red materials. The area of specific interest is transmission window materials for the far infra-red (8-12  $\mu\text{m}$ ), which perform better than ZnS in at least one respect, without any trade-off in other properties.

The work reported here has targeted a new class of amorphous super-phosphides as having significant potential as IR materials, and has developed these materials in three stages.

- 1) Proof of concept on a model system
- 2) Screening of the potentially useful members of this class
- 3) Evaluation of ternary compounds, and selection of an overall winner

Due to a reduction in funding in the last year of the programme, stage 3 did not select an individual winner, but the super-phosphides of Ge, Ga and Zn have been selected as worth further investigation.

Prepared by : G. A. Scarsbrook  
Approved by : R. A. Heinecke  
Authorised by: P. W. Graves  
Issued : June 1990

1987-89 Final Report  
(01 Oct 1987 - 31 Dec 1989)

ONR CONTRACT INFORMATION

Contract Title:	PULSED PLASMA PREPARATION FOR LW-IR MATERIALS
Contract Number:	N00014-87-J-1275
Work Unit No:	431-A-018
Scientific Officer:	Dr. R. W. Schwartz, Naval Weapons Center
Key Scientific Staff:	Dr. G. Scarsbrook R. A. Heinecke Dr. I. P. Llewellyn K. J. Sheach
STL Manager:	Dr. P. W. Graves

-11-  
CONTENTS

	Page
1. OBJECTIVE	1
2. INTRODUCTION	1
3. PHOSPHORUS RICH PHOSPHIDES	2
3.1 Design of New LW-IR Materials	2
3.2 STAGE 1: Deposition and Characterisation of the Model System $\text{GeP}_x\text{S}_y$	3
3.3 STAGE 2: Screening of Binary Phosphides	4
3.3.1 Boron Phosphide	5
3.3.2 Carbon Phosphide	5
3.3.3 Aluminium Phosphide	6
3.3.4 Silicon Phosphide	7
3.3.5 Zinc Phosphide	7
3.3.6 Gallium Phosphide	8
3.3.7 Cadmium Phosphide	8
3.4 STAGE 3: Evaluation of Ternary Compounds	9
4. CONCLUSIONS	9
5. REFERENCES	10
6. APPENDICES	21
APPENDIX A - Development of pulsed plasma equipment and process	
APPENDIX B - Phosphorus - the anion for LWIR materials	
APPENDIX C - Phosphine safety measures in PACVD processing	

LIST OF TABLES AND FIGURE CAPTIONS

- Table 1: Table of the binary and ternary phosphides examined during 1988-89, showing and measured band gap (i.e. energy at  $\alpha=10^3$  and  $\alpha=10^4$ , see text) and Vickers microhardness data (50g load, 10 seconds application).
- Figure 1: A plot of the variation in band gap, measured by the 5% transmission point, of germanium phosphide as a function of composition. Also included are two data points from the ternary GePS, showing the enhanced effect of S over P in increasing the band gap.
- Figure 2: Infra-red transmission curves of  $\text{GeP}_{3.5}$  showing the film i) as deposited, ii) after annealing at  $300^\circ\text{C}$  for 1 hour, and iii) after water immersion for 1 hour. The latter two curves are displaced along the Y axis by 20% and 40% respectively for clarity.
- Figure 3: Infra-red transmission curve of a  $20\mu\text{m}$  film of  $\text{GeP}_2\text{S}$  on a Ge substrate.
- Figure 4: Plot of the measured bandgap data (i.e. energy at  $\alpha=10^3$  and  $\alpha=10^4$ , see text) of the binary and ternary phosphides, before and after annealing in  $\text{N}_2$  at  $300^\circ\text{C}$  for 2 hours.
- Figure 5: Infra-red transmission curve of  $3.8\mu\text{m}$   $\text{CP}_{13}$  film on Ge, with Ge substrate background curve subtracted.
- Figure 6: Infra-red transmission curves of  $4\mu\text{m}$   $\text{AlP}_{13}$  film on Ge, with Ge substrate background curve subtracted. The upper trace shows the film as deposited, whilst the lower trace shows the film after a 2 hour water immersion.
- Figure 7: Infra-red transmission curve of a  $2.9\mu\text{m}$   $\text{ZnP}_{3.5}$  film after an anneal at  $400^\circ\text{C}$  for 2 hours.

Figure 8: IR transmission curves of a  $7.6 \mu\text{m}$   $\text{GaP}_{1.9}$  film on a Ge substrate. The middle trace shows the film on substrate as-deposited, and the bottom trace shows the result after a 2 hour  $400^\circ\text{C}$  anneal, whilst the top trace shows the Ge substrate only for comparison.

Figure 9: IR transmission curves of a  $3.7 \mu\text{m}$   $\text{SiP}_2$  film on a Ge substrate. The second curve shows the film on substrate as-deposited, and the third trace the result after a 3 hour anneal at  $500^\circ\text{C}$ . The top trace shows an uncoated Ge substrate for comparison. In addition, the fourth trace shows a  $4.5 \mu\text{m}$   $\text{ZnSiP}_{3.5}$  on Ge, as-deposited.

Figure A1: Schematic of the pulsed plasma reactor. The inset shows the RF electrode in detail.

Figure C1: Schematic of the automatic oil change system fitted to the mineral oil rotary pump. This system enables the phosphine contaminated oil in the pump to be changed whilst keeping it within a sealed (extracted) environment.

## PULSED PLASMA PREPARATION FOR LW-IR MATERIALS

### 1. OBJECTIVE

The objective of this programme has been to prepare and evaluate new long wavelength infra-red transparent materials, using the novel high energy pulsed plasma technique developed at STC Technology Ltd (STL). New materials are required to out-perform the current materials (ZnS) in at least one aspect, without any trade-off in the other properties.

### 2. INTRODUCTION

The 8-12  $\mu\text{m}$  window material predominantly used in current IR applications is ZnS, since this material exhibits the best available compromise between the properties required. However, the rain erosion and thermal shock performance of ZnS is insufficient to satisfy the specifications of all current and future applications, and it starts to cut off in transmission before 12  $\mu\text{m}$  at operating temperatures above 700°C.

Many years of research using conventional preparation techniques have failed to identify a replacement material for ZnS, in part due to the time required in conventional processing techniques, and partly because of their limitation to thermodynamically stable phases. A possible exception to this generalisation is CVD diamond film, and hence there has been rapid growth in this area although practical diamond domes are still very distant.

The novel pulsed plasma deposition process, developed at STL, is an ideal tool for rapid preparation and evaluation of new materials. This programme has used pulsed plasma for the rapid development of new infra-red transparent materials. The search is targeted particularly on bulk materials for the 8-12  $\mu\text{m}$  window to replace ZnS. Details of the pulsed plasma technique are given in Appendix A.

A new class of amorphous phosphorus-rich phosphides has been identified, with considerable promise for a replacement for ZnS. Members of this class of materials which are of particular interest are ZnP, GeP, GaP, and the ternaries ZnSiP and GePS.

### 3. PHOSPHORUS RICH PHOSPHIDES

#### 3.1 Design of New LW-IR Materials

The study for new IR materials has to find a compromise to the two conflicting needs:

- i) IR transmitting materials must have weak covalently bonded structures, low atomic co-ordination, and heavy atoms, in order to avoid phonon absorption within the IR window required.
- ii) Conversely, for both strength and for a wide band gap to avoid free electron absorption as the temperature rises, the material requires strong bonds and light atoms.

For window applications, the mechanical properties of the window material are as important as the IR transmission. The use of a heavy anion results in poor mechanical properties and a low band gap because of the d electrons. This would suggest that phosphorus and sulphur are the only choices for the anion, relying on a heavy cation to lower the phonon frequencies. It is, perhaps, not surprising that zinc sulphide has to date been so successful as a window material.

Phosphorus is a unique element, capable of forming similar fully bonded structures in both crystalline and X-ray amorphous forms. This enables defect free binary materials to be produced in amorphous form by PACVD techniques. The thermal stability of elemental phosphorus varies enormously depending on the particular allotrope, but continuously bonded three-dimensional networks, such as found in black phosphorus, are quite stable. This type of bonding, in conjunction with the correct cation addition, can result in amorphous structures which are hard, have a moderately wide band gap, and transmit beyond 12  $\mu\text{m}$ . A literature study of

phosphorus and its compounds is presented in Appendix B.

Sulphur does not have the same potential as phosphorus for forming single anion amorphous materials, since its two bonds make it chain forming rather than network forming. Mixed phosphide/sulphides have proven inferior to phosphides, during this programme (Sec. 3.2), due to IR absorption near 12  $\mu\text{m}$ .

The experimental work on phosphides was split into three stages:

- 1) Evaluating the effects of composition and sulphur additions in the model system  $\text{GeP}_x\text{S}_y$ .
- 2) Screening the phosphorus-rich binary compounds.
- 3) Studying selected ternary compounds.

### 3.2 Stage 1: Deposition and Characterisation of the Model System $\text{GeP}_x\text{S}_y$

In the first stage, completed mainly in 1988, GeP and GePS were prepared in a wide range of compositions as homogeneous, amorphous, well-adherent films onto silicon or germanium substrates. The properties of the films were shown to vary continuously with composition, and in particular the band gap of  $\text{GeP}_x$  could be varied from ~ 0.9 to 1.6 eV, as x varied from 0.5 to 6 (Figure 1).  $\text{GeP}_x$  showed no specific absorption peaks between 3 and 20  $\mu\text{m}$ , down to a resolution of  $< 5 \text{ cm}^{-1}$ , with excellent chemical stability (Figure 2), and a hardness of ~300 Hv. Additions of sulphur were shown to increase the band gap ~5 times as quickly as P, but also to add weak IR absorption at 12  $\mu\text{m}$  and beyond (Figure 3). Scratch testing identified that as S was added to GeP the hardness of the film decreased to a minimum and then started to recover again. Annealing of the films was shown to increase the band gap by ~ 0.15 to 0.3 eV, which was modelled as an increase in chemical (bonding) order [1].

### 3.3 Stage 2: Screening of Binary Phosphides

Stage two, commenced in 1989, was a rapid screening of the other binary materials; BP, CP, AlP, SiP, ZnP, GaP, and CdP although the latter was later excluded because of its low bandgap. Of these, both AlP and SiP have shown intrinsic absorption in the 8-12  $\mu\text{m}$  window; these compounds also showing some long term instability.

In preparation for the deposition of the phosphorus-rich binaries, the deposition of phosphorus was first investigated. It was found that the deposition rate was critically affected by the dc bias generated on the RF electrode, even when using the hollow electrode configuration. The phosphorus was apparently re-sputtered when the bias was high, or when a buffer gas of Ar was used; and an He buffer gas was required. Consequently, exclusion of hydrogen was difficult in pure phosphorus films (though the majority annealed out), but the optical band gap was found to be encouragingly large (1.72 eV at  $\alpha=10^4$ ) with a well defined cut-off, and IR transmission data showed transmission to beyond 20  $\mu\text{m}$ , with no evidence of intrinsic absorption. These results are in agreement with reported IR absorptions [2], namely:

P-P	510-390	$\text{cm}^{-1}$	measured
	450	$\text{cm}^{-1}$	calculated
P-H	2457-2240	$\text{cm}^{-1}$	stretch ) measured
	1150-800	$\text{cm}^{-1}$	deform )

When depositing the binary phosphides in the hollow electrode, the apparent sputtering of phosphorus was not observed, presumably due to the greater stability of the binaries, and deposition conditions could be better optimised. However, not all of the binaries were produced entirely hydrogen-free. Some of this problem early in the year was due to failure in the RF generator, resulting in lower power levels than indicated, and leading to incomplete dissociation. However, even at higher power levels a small amount of hydrogen remained in the BP and SiP, though particularly in the SiP this could be largely annealed out. Hydrogen in these materials results in two absorption peaks, near 4.5  $\mu\text{m}$  and 11-12  $\mu\text{m}$ , the latter peak being confirmed as hydrogen by the correlation between its intensity and

that of the former peak during annealing. Hydrogen retention in BP is perhaps not too surprising, since the B-H-B bridge is very stable, but the reason for hydrogen inclusion in SiP is uncertain.

Table 1 shows all the binary phosphides deposited, giving band gap and hardness data. Figure 4 displays graphically the band gap data for direct comparison. The band gap data in this work has been obtained by observing the energy at which the optical absorption coefficient  $\alpha$  reaches  $10^3$  and  $10^4$ , these being typical values of  $\alpha$  at the band edge as predicted by the various theoretical models [3]. This approach is used in preference to complex analysis such as a Tauc plot which, based on a particular model, may be in error and therefore misleading. Recording the energy at two absorption values allows the sharpness of the band edge to be measured. Details of the phosphides prepared are given below:

### 3.3.1 Boron Phosphide

#### Reported IR data: [2]

P-B	750-550	cm <sup>-1</sup>	measured
P-B	1500-1400	cm <sup>-1</sup>	measured
P-B	666	cm <sup>-1</sup>	calculated

Experimental Data: Boron phosphide is a difficult material to prepare in bulk for IR applications by methods other than CVD. Its application may be limited by weak absorption near 12  $\mu\text{m}$ , though this probably results from hydrogen inclusion. As noted earlier, all BP films prepared in this programme have shown significant hydrogen absorption in this region, but effort was concentrated on other phosphides since BP was being evaluated elsewhere.

### 3.3.2 Carbon Phosphide

#### Reported IR Data: [2]

P-C	780-620	cm <sup>-1</sup>	measured
	719	cm <sup>-1</sup>	calculated
P-CH <sub>2</sub> -P	845-795, 770-720	cm <sup>-1</sup>	measured
P-C	1230-1180	cm <sup>-1</sup>	measured

**Experimental Data:** The observed deposition rate of carbon phosphide was found to be anomalously low, and the measured composition of the film deposited was not that expected. In particular, even at gas compositions corresponding to near  $CP_1$ , the film composition was  $CP_{>12}$ . This effect appeared initially to result from mutual etching of carbon and phosphorus, though later results are more ambiguous and have made evaluation of this binary difficult.

Despite these difficulties, no intrinsic absorption has been observed in CP films; the absorption at  $750\text{ cm}^{-1}$  (Figure 5) is probably hydrogen, resulting from the constraints on the deposition window. Annealing of CP films, shifts the optical cutoff a long way into the blue, suggesting that major structural changes occur, and perhaps suggesting that full bonding does not occur during deposition.

Carbon can also be incorporated, to at least 10% levels, in ternaries from organo-metallics (e.g. containing Al and Zn), where no IR absorption or other detrimental effects associated with the carbon are seen. Some mutual etching of phosphorus and carbon occurs in these cases, resulting in a film stoichiometry different to the gas composition, but in a manner which is repeatable and largely predictable.

### 3.3.3 Aluminium Phosphide

**Reported IR Data:** [2]

Al-P  $406\text{ cm}^{-1}$  calculated

**Other Reported Data:** AlP is normally considered chemically unstable with respect to hydrolysis and formation of  $PH_3$  as a result of the exceptional stability of  $Al_2O_3$  (and consequently it is often used as a fumigant). Its stability is thought to increase with purity. The thermal conductivity of crystalline AlP is high ( $\sim 1.3\text{ Wcm}^{-1}\text{K}^{-1}$  at room temperature).

**Experimental Data:** Initial films of aluminium phosphide, deposited from trimethylaluminium (TMA) and  $PH_3$ , were unstable at all compositions, as were ternaries such as AlGeP. By using a capping layer of

GeP on an AlP film, an IR transmission curve of AlP was obtained. This curve showed only weak absorptions in the 8-12  $\mu\text{m}$  window, which were thought to be extrinsic, and this encouraged further development. Following the repair and recalibration of the RF generator, so that higher power levels were achieved,  $\text{AlP}_x$  films with  $x > 7$  were deposited which were stable in room air (~1 week), water (~2 hours, see Figure 6), and nitrogen gas annealing up to 300°C (small unidentified peaks arising at 400°C). However, at compositions below  $\sim\text{AlP}_4$  the films were still unstable, hydrolysing in room air, and the long term stability of higher aluminium phosphides is in doubt. IR spectroscopy shows an apparently intrinsic absorption starting weakly near 800  $\text{cm}^{-1}$  and strengthening towards 400  $\text{cm}^{-1}$ . At lower deposition rates, carbon inclusion can be kept very low (<1%). However, at higher deposition rates (>0.5 Å per pulse) significant carbon is incorporated, though this appears not to affect the stability. The hardness of an  $\sim\text{AlP}_7$  ( $\text{C}_{0.3}$ ) film was measured as 388 Hv, though the film showed significant brittle cracking at the indentation corners. Higher hardness values may be obtainable with compositions nearer AlP, but have not been measured because of the instability of the material.

#### 3.3.4 Silicon Phosphide

Reported IR Data: [2]

P-Si	515-414	$\text{cm}^{-1}$	measured
	434	$\text{cm}^{-1}$	calculated

Experimental Data: The experimental data for SiP is described with the ternary materials in Sec. 3.4.

#### 3.3.5 Zinc Phosphide

Experimental Data:  $\text{ZnP}_x$  compounds are particularly easy to deposit, free of hydrogen and with the IR transmission curve showing only a small sharp peak at 900  $\text{cm}^{-1}$ . This peak is thought to be extrinsic, but currently is unidentified. At low deposition rates carbon can largely be excluded from the films, but at moderate rates (0.5 Å/pulse) carbon is incorporated, but does not appear deleterious to the film. This is similar behaviour to that seen with the  $\text{AlP}_x$  growth. Films of ZnP are stable in

water and after annealing at 300°C (Figure 7). Hardness testing measured 276 Hv but showed significant brittle or interface failure; the latter would result in a low value. For comparison, optical quality ZnS was measured as 190 Hv by the same technique.

### 3.3.6 Gallium Phosphide

Reported IR Data: [2]

P-Ga	370-320	cm <sup>-1</sup>	measured
	339	cm <sup>-1</sup>	calculated
Bulk GaP absorbs at 366 cm <sup>-1</sup>			

Other Data: Gallium phosphide is well known as a bulk crystalline semiconductor. Its thermal conductivity is then 1.0 Wcm<sup>-1</sup>K<sup>-1</sup>, the band gap 2.25 eV, the hardness 845 Hv and the refractive index 2.9. Bulk GaP is being evaluated under the ONR programme as an IR dome material, where its main limitation would appear to be absorption at the long wavelength side, particularly as the temperature increases above 500°C. This problem may be reduced in amorphous material.

Experimental Data: Amorphous phosphorus-rich GaP is similar to AlP and ZnP in deposition conditions and behaviour with deposition parameters. The IR transmission spectrum shows absorption starting above 10  $\mu$ m due largely to hydrogen (Figure 8), which can be partially annealed out at 400°C, and largely removed at 500°C. Higher RF pulse powers may cure the hydrogen inclusion. The environmental tests (water, moist room air) do not result in any change in the IR spectrum, but the material does emit an odour of phosphine, so long term stability needs further evaluation.

### 3.3.7 Cadmium Phosphide

Initial work on cadmium phosphide showed that the band gap was very small, resulting from the heavy cation, and this material was excluded from further analysis.

### 3.4 Stage 3: Evaluation of Ternary Compounds

Stage three compared the ternary ZnSiP with the two component binary phosphides. Figure 9 shows a SiP<sub>2</sub> film as-deposited, as-annealed, and compared with a ZnSiP<sub>3.5</sub> film. The following points can be noted:

- a) Even at higher powers, up to 30 kW, some hydrogen was always incorporated in SiP, giving rise to peaks at ~2200 and ~700 cm<sup>-1</sup> which largely annealed out at 400°C and above.
- b) Intrinsic absorptions in SiP are seen at ~500 cm<sup>-1</sup> (fundamental: very strong) and 1000 cm<sup>-1</sup> (harmonic: moderate). The latter peak, however, decreases slightly with annealing at 400°C, and further at 500°C to about half its initial intensity. In addition, in more phosphorus-rich compositions, the 1000 cm<sup>-1</sup> peak is proportionately weaker than the 500 cm<sup>-1</sup>.
- c) Addition of Zn to SiP moves the harmonic SiP absorption to longer wavelengths.

These observations make SiP a very interesting system to study. Since SiP shows good mechanical properties (e.g. 420 Hv), if the harmonic absorption peak can be moved entirely out of the IR window by ternary additions, then SiP based ternaries could be important. More probable, however, is that the SiP system could enable rapid study of this type of chemical addition effect, which in turn could be applied to other binaries such as ZnGeP<sub>2x</sub>.

## 4. CONCLUSIONS

Eight binary phosphides, novel in both composition and structure, have been investigated for use in IR applications. Excluding cadmium phosphide, in which the band gap was too small, all the phosphides are harder than ZnS. In addition, most are IR transparent in the regions of interest, though hydrogen inclusion tends to occur in those phosphides with the lighter cations (causing absorption near 12 μm) and silicon and aluminium phosphides exhibit absorption. Aluminium phosphides have for the

first time been made stable, at least at the higher phosphorus contents, and addition of zinc to silicon phosphide has demonstrated the potential of ternary additions in beneficially modifying absorption characteristics and mechanical properties. In view of the latter data, the ternary zinc germanium phosphide offers great potential. This ternary is expected to be harder than either binary, with a larger band gap, and any weak absorptions beyond 12  $\mu\text{m}$  are expected to move further away. Gallium phosphides are also still of interest, but are considered of lower priority.

#### REFERENCES

1. G. Scarsbrook, I. P. Llewellyn, R. A. Heinecke, J. Vac. Sci. Technol. A 7(3), June 1989, p1099.
2. D. E. Corbridge, Topics in Phosphorus Chemistry, Vol. 6, Series Editors, M. Grayson and E. J. Griffith, Interscience (1975).
3. N. F. Mott and E. A. Davis, Electronic Processes in Non-Crystalline Materials, 2nd Edition, International Series of Monographs on Physics, Series Eds. W. Marshall and D. H. Wilkinson, Clarendon Press, Oxford, 1979.

Binary addition	Band gap (eV)		Hardness* Hv (50g)	Comments
	E at $\alpha=10^3$	E at $\alpha=10^4$		
B	1.33 (1.46)	BP1.7 1.72 (1.77)	BP1.7 806 (759) <sup>1</sup>	n = 3.1 $\pm$ 0.1 High power required to exclude hydrogen
C	1.24 (1.72)	CP1.3 1.70 (2.30)	-	Mutual etching of C & P
Al	1.35	AP7 1.65	AP7 388	AlP <sub>x</sub> , x $\geq$ 7, stable $\geq$ week
Si	1.46 (1.73)	SIP12 1.89 (2.06)	SIP2 420	Some adhesion problems. Indication of long term instability. n = 2.9 $\pm$ 0.1
P only	1.72	1.97	-	Difficult to deposit (sputtering). Some hydrogen inclusion.
Zn	1.61 (1.61)	ZnP3.5 1.91 (1.93)	-ZnP2 276	
Ga	1.49 (1.51)	GaP1.9 1.80 (1.81)	GaP1.9 728	
Ge	- (1.03)	GeP3 1.08 (1.35)	(-300)	
Cd	1.22	CdP3 1.43		
ZnSi	1.46 (1.62)	ZnSIP4 1.80 (1.92)	559 (453) <sup>1</sup>	n = 3.0

\*ZnS measured as 190 Hv    ( ) = anneal 300°C/2hr in nitrogen    <sup>1</sup> Suspected adhesion failure

Table 1: Band Gap and Hardness Data for the  
Binary Phosphorus-Rich Phosphides




Figure 1: Variation of 5% Optical Transmission Point with Composition in  $\text{GeP}_x$




Figure 2: IR Transmission Spectra of GeP<sub>3.5y</sub> Thin Films after Various Treatments




Figure 3: IR Transmission Spectra for 10 μm Thick Film of GeP<sub>2</sub>S




Figure 4: Optical Absorption Edge Characteristics of Binary Super-Phosphides before and after Annealing




Figure 5: IR Transmission Spectrum for 3.8  $\mu\text{m}$  CP<sub>13</sub> on Ge




Figure 6: IR Transmission Spectra of AIP Before and After Annealing




Figure 7: IR Transmission Spectra of ZnP After Annealing




Figure 8: IR Transmission of As-Deposited and Annealed GaP




Figure 9: IR Transmission Spectra of SiP and ZnSiP

## APPENDIX A

## DEVELOPMENT OF PULSED PLASMA EQUIPMENT AND PROCESS

## A1 BASIC ARRANGEMENT

Pulsed plasma deposition uses high powered RF pulses to fully dissociate precursor gases at low pressure, causing atomic deposition onto a substrate.

The plasma reactor used is in the form of a 6-way 100 mm diameter cross, with electrodes entering from the top and bottom, gas flow from right to left, and a viewing window at the front (Figure A.1). Gas pumping is by a roots rotary combination with nominal pumping speed of  $500 \text{ m}^3\text{h}^{-1}$ . Typical operating pressures are 50-300 mTorr, as measured by a capacitive manometer connected directly to the chamber. The pumping speed at the chamber is controlled by an automatic throttle valve.

Gas flow through the chamber can either be continuous, with sufficient velocity to ensure new gas for each RF pulse, or be pulsed synchronously with the RF, in which case the gas composition can be uniquely selected for each pulse. Further details can be found in [1, 2].

The electrode configuration used has a significant effect on the induced DC bias on the RF electrode. In particular, the standard parallel electrode arrangement results in typical bias values of 2-3 kV, whilst the hollow cup electrode (Figure A.1) can reduce this to ~ 200-300 V. In order to obtain high quality films, it was found necessary to place the substrate in the hollow cup RF electrode; higher bias values causing sputtering of the film. Several electrodes of different dimensions were used, but typical dimensions were: external diameter 108 mm, internal diameter 86 mm, depth 20 mm, with a conformal insulator of external diameter 129 mm. The electrode top plate was 5 mm thick with a centre hole 49 mm in diameter.

## A2 PROCESS DEVELOPMENTS DURING THIS PROGRAMME

A2.1 Vapour Handling

With the great emphasis in this programme on vapour sources with vapour pressures between 3 and 200 Torr at room temperature, significant effort has been put into improving the handling of these sources. A recently developed vapour flow controller from Vacuum General, the LC2, has been installed on the plant on a 0.5 inch vapour line with its own heated Baratron pressure gauge. Since it runs internally at 70°C, vapours up to this temperature can be handled. However, the in-line impedance of this controller is so low (2 orders of magnitude below normal flow controllers) that all the vapours have been handled at room temperature, greatly improving reliability and ease of operation. Gas flow factors for the vapours have been derived by measuring the rate of pressure rise in a known volume. The values derived are:

TMA (trimethylaluminium)	0.037 ± 15%
DEZ (diethylzinc)	0.17 ± 15%
TMG (trimethylgallium)	0.23 ± 15%
DMC (dimethylcadmium)	0.30 ± 15%

(NB. TMA is thought to be dimeric under the conditions of test and use).

Stable (calibrated) flow rates of above 100 sccm from room temperature source bottles can easily be obtained with TMA, an order of magnitude better than was previously possible.

A2.2 Reactor Chamber

When using high power and a hollow RF electrode to control the bias, arcing at the walls of the 4-inch, 6-way cross reactor chamber sometimes became a significant problem. This was considered to be due largely to the relative sizes of the electrodes to the chamber, and so rather than reduce the electrode size, which reduces the effectiveness of the hollow electrode design, the reactor was replaced with a 6-inch, 6-way cross. Arcing problems have been substantially reduced by this

modification.

### A2.3 Safety Aspects

Phosphine has been used extensively during the preparation of LWIR super phosphides, and many safety precautions were taken at the onset of the work and others developed during it. The main features are given in Appendix C.

### A3 REFERENCES

- 1) G. Scarsbrook, I. P. Llewellyn, S. M. Ojha, R. A. Heinecke, Vacuum 38(8/10), 1989, p627.
- 2) G. Scarsbrook, I. P. Llewellyn, R. A. Heinecke, J. Vac. Sci. Technol. A 7(3), June 1989, p1099.




Figure A.1: Pulsed Plasma Capacitive Reactor

## APPENDIX B

## PHOSPHORUS - THE ANION FOR LWIR MATERIALS

## B1 INTRODUCTION

The pulsed plasma development of new IR materials began in 1987 under this ONR programme, looking at the model system  $\text{GeP}_x\text{S}_y$ . The early results indicated that this amorphous material exhibits a reasonably sharp optical cutoff, with a sufficiently high band gap to limit free electron absorption in the IR. In addition, its chemical stability was shown to vary with composition, increasing to a high level with phosphorus content up to  $\text{GeP}_x$ : $x=3.5$  or more. These results prompted a review of the field of amorphous polyphosphides, given in this appendix, and the selection of a range of potentially suitable cations for which volatile sources could be found. Both the theoretical and experimental studies have confirmed the uniqueness of phosphorus and the polyphosphides, and their potential in IR window applications.

Any study for new IR materials has to find a compromise between:

- i) The need for weak covalent structures, with low co-ordination and heavy atoms, which push the phonon absorption bands out beyond the far infrared requirement.
- ii) The need for strength, and a large band gap to limit free electron absorption at higher temperatures.

This appendix shows why amorphous phosphorus-rich phosphides have a major potential in fulfilling these requirements.

Phosphorus is the heaviest trivalent anion available which has no d electrons. Its weight moves the phonon bands further into the far infra-red, whilst its trivalent bonding allows three-dimensional network forming (unlike divalent sulphur). Absence of d electrons enhances the

mechanical properties and the band gap.

The choice of phosphorus is influenced by the amorphous nature of the films we deposit. Being trivalent, not only can phosphorus form amorphous three-dimensional networks, but these are not as strained as those of the tetravalent elements such as silicon, because of the reduced constraints. Elemental phosphorus forms a large number of allotropes, with widely varying properties. White phosphorus, for example, is formed from highly strained tetrahedral  $P_4$  molecules weakly bonded together, resulting in a highly reactive material. In contrast, black phosphorus forms long range structures in both crystalline and amorphous forms, and is quite stable. Pulsed plasma deposited phosphides are more nearly related to black phosphorus, and can also show good stability.

## B2 CONVENTIONAL PHOSPHIDES

The various crystalline phosphides differ greatly in their physical and chemical properties. These differences can, to a degree, be related to their structural geometry. The great majority of established phosphides range in composition from  $M_3P$  to  $MP_3$ , with most metals forming at least one compound in this range. They are classified as metal rich ( $P < 60\%$ ) or phosphorus rich ( $P > 60\%$ ) with the monophosphides in the middle. Metal-rich phosphides are usually hard, brittle, and electrically conductive, and have high thermal and chemical stability. Phosphorus-rich varieties are typified by lower melting points, much lower thermal stability, and are usually semiconductors. On heating, phosphorus-rich compounds revert to metal-rich compounds, with the evolution of phosphorus. The structures adopted by metal-rich compounds appear to be influenced mostly by radius ratio factors, whereas valency electrons and directive covalent bonds are more significant in the P-rich varieties. Some phosphides of groups I and II metals are decomposed by water to produce phosphine and are believed to have some ionic bonding.

### B2.1 Monophosphides and Related Phosphides

The crystalline monophosphides BP, AlP, GaP and InP form a series of isomorphs with the zinc blende type structure. In these, each

atom is tetrahedrally co-ordinated by atoms of the other type to form a continuous 3-D covalent structures. These monophosphides all have semiconductor properties and their high carrier mobility and wide band gaps suggest their use at high temperatures. They all have high thermal conductivities.

Phosphide	Density (gcm <sup>-3</sup> )	Melting point (°C)	Hardness (Moh's)	Lattice Spacing (Å)	Thermal Cond. (Wm <sup>-1</sup> K <sup>-1</sup> )
BP	2.89	2500	9.5	4.538	4000
AlP	2.42	1800	5.5	5.451	1300
GaP	4.10	1467	-	5.436	1000
InP	-	1058	-	5.87	-

### B3 THERMAL CONDUCTIVITY IN PHOSPHORUS-RICH PHOSPHIDES

Amorphous materials are generally considered to be poor thermal conductors, whereas high thermal conductivity is required for most IR dome applications. However, it is probable that these unique phosphorus-rich phosphides show higher thermal conductivities than other amorphous materials.

The effect on thermal conductivity in going from a crystalline material to amorphous material is to limit the mean free path of the phonons to the scale of the chemical unit (probably of the order of a P<sub>4</sub> unit in white phosphorus, for example), thus reducing the thermal conductivity K.

$$K = \frac{1}{3}C_v l v$$

where v = velocity of sound

C<sub>v</sub> = the specific heat

l = phonon mean free path

Typically, for a crystalline material, l is limited by the sample bounds up to about 10 K, resulting in a T<sup>3</sup> dependence of conductivity on the specific heat. Above this temperature, the

conductivity rapidly falls due to phonon-phonon interactions, reducing the mean free path. In an amorphous material, the initial rise is of  $T^2$  dependence, and continues to rise above 10 K, so that as T increases to 100 K and 1000 K, the two conductivities are converging. However, the thermal conductivity of amorphous materials near room temperature is typically 1 or 2 orders of magnitude down on its crystalline counterpart.

For the polymeric phosphorus structures, the distinction between crystalline and amorphous is much weaker, so that the loss of thermal conductivity on going to amorphous materials may be proportionately less. We can then anticipate a thermal conductivity on the lower end of the scale between that of the crystalline monophosphide (very much higher than ZnS), and that of the elemental amorphous black phosphorus ( $13.2 \text{ Wm}^{-1}\text{K}^{-1}$ , slightly lower). Clearly the thermal conductivity is an important parameter to measure, but it is likely to be particularly sensitive to composition and preparation details (i.e. structure).

#### B4 THE STAUFFER PATENT

This summary of the Stauffer patent, brought to our attention by Dr. J. A. Savage, RSRE, is an illustration of some of the unique properties of the polyphosphides.

UK Patent: GB2 113 663A

Applicant: Stauffer Chemical Company, Westport, Connecticut, USA

Subject: High phosphorus polyphosphides

i.e.  $\text{MP}_x$  where M = alkali metal (Li, Na, K, Rb, Cs)  
or metals with similar bonding

and  $x = 7 - 15$

or  $x \gg 15$

(polyphosphide implying dominated by polymeric P-P bonding).

The materials are characterised by their useful properties:

- Stability
- Bandgap 1.4-2.2 eV, typically 1.8 eV

- High inherent resistance, but with ability to be doped (using Ni).
- Good photoconductivity
- Efficient luminescence
- Ability to form a rectifying junction

These single-crystal properties are also retained in the amorphous state.

The crystalline form of the polyphosphides of type  $MP_{15}$  consists of a phosphorus skeleton of parallel tubes of pentagonal cross-section, linked by P-M-P bridges. The useful electrical and optical properties of  $MP_{15}$  materials are preserved in the  $MP_x$  ( $x \gg 15$ ) materials, being dominated by the P-P bonding of the phosphorus skeleton which has an average co-ordination number a little less than 3. Since K does not form lower phosphides than  $KP_{15}$ , unlike the other alkalis in the  $KP_x$  system, is easier to control, and is therefore the preferred system. The formation of amorphous  $KP_{15}$  is also found to occur under any deposition conditions where the temperature is not sufficiently high to cause crystallisation, and high enough that  $KP_x$ ,  $x \gg 15$ , is not deposited. In both the crystalline and amorphous  $MP_{15}$ , the local order is the same, that of locally parallel elongated phosphorus tubes with pentagonal cross-section, double layers of the tubes being held together by interstitial alkali metal atoms. P-P bonds are 12.13 to 2.58 Å, with a bond angle of  $87^\circ$  to  $113^\circ$ , average  $102^\circ$ .

#### The Role of the Metal

The many allotropes of phosphorus illustrate its structural versatility, and the metal atoms are believed to contribute by making more stable the particular structure which is desirable. Clearly only a small amount of metal is required. Apart from the alkali metals, tubular phosphorus structures have been reported in 2b-4a- $P_{14}$  compounds (2b=Zn, Cd, Hg, and 4a=Sn, Pb).

#### Mechanical Properties

$MP_x$  materials, particularly  $MP_{15}$ , can be deposited as amorphous films with good adhesion to metals and glass. The films are ductile, non-porous, polymeric and non-brittle.

## B5 SUMMARY

It is concluded that:

- 1) Phosphorus can form very stable, hard materials in binary and higher compounds.
- 2) Phosphorus is heavier than nitrogen and oxygen, and forms weaker bonds, so that many M-P (M = metal or cation) bonds do not show phonon absorption at less than 12  $\mu\text{m}$ .
- 3) Conversely, phosphorus has no d electrons, and forms harder, more stable compounds with wider bandgaps than the other pnictides.
- 4) The critical thermal properties, particularly the conductivity, can potentially exceed those of ZnS, but will be sensitive to the exact material composition. Consequently this parameter should be refined after other less sensitive parameters have been used to select the particular materials of interest.

## B6 BIBLIOGRAPHY

- 1) Structural Chemistry of Phosphorus, D.E.C. Corbridge, Elsevier, Scientific Publishing Company, London, 1974.
- 2) The Structure of the Elements, Jerry Donohue, Wiley-Interscience, London, 1974.
- 3) UK Patent: GB2 113 663 A, Stauffer Chemical Company, Westport, Connecticut, USA. On High Phosphorus Polyphosphides.
- 4) Encyclopedia of Chemical Technology, 3rd Ed., Volume 17, Editorial Board H.F. Mark, D. F. Othner, C. G. Overberger, G. T. Seaberg, Pub. Wiley-Interscience, 1982.

## APPENDIX C

## PHOSPHINE SAFETY-MEASURES IN PACVD PROCESSING

## C1 INTRODUCTION

STL's unique pulsed plasma deposition process has been used in the development of new LWIR materials, because of its ability to rapidly create new materials from gaseous precursors. Many of these precursors are toxic, particularly the hydrides and the organometallics. Whilst phosphine is not the most toxic of the hydrides used, it presented the greatest hazard since it has been used in the greatest quantity (2-3 kg per year, over ~ 3 years).

The toxicity limit value (TLV) of phosphine is 0.3 ppm, but its initial odour threshold is much lower (by  $> 10^1$ ) than this, making it unlikely that personnel could be exposed to a toxic level suddenly without detecting it. Extended exposure does dull the sensitivity (olfactory fatigue), so it is important to monitor working and storage areas.

The extent of the hazard to prolonged low exposure to phosphine is uncertain, though recent research suggests genetic damage may occur with exposure levels below but near TLV [1]. The short term symptoms of exposure are reasonably well documented (faintness, apathy, nausea, vomiting etc.), and severe exposures resulting in permanent injury and death have been reported [2].

The initial policy of this programme was to build in all safety precautions which were evident at the time. Experience, together with the recent publications, prompted further measures to be installed.

## C2 INITIAL PRECAUTIONS

C2.1 Gas Monitoring

Hydride monitoring equipment was installed on each plasma

machine, also in the two gas storage huts. This equipment is of the paper tape variety (MDA TLD-1), allowing easy testing and servicing together with a guaranteed maximum reliability. With several hydrides present in the laboratory, these instruments were calibrated for the TLV level of germane, which is the most difficult to detect, resulting in a much lower than TLV threshold for the other hydrides including phosphine.

In addition, a small portable hand sniffer (Union Carbide Gas Leak Detector) was purchased. Its main application is for 'sniffing' for hydrogen as a method of isolating minor leaks, but it is also capable of detecting phosphine.

#### C2.2 Source Gas Handling

Specialist gas storage huts, in the open with full extraction and monitoring, were constructed by STL site services to hold the source cylinders. Gas lines into the plasma processing cleanroom were constructed from fully welded stainless steel tubing, with bellow sealed valves. Specialist gas pressure regulators were installed, with cross purging using argon and pumping down to vacuum. All lines were fully pressure tested and vacuum tested, and vacuum testing is incorporated into the cylinder change procedure.

#### C2.3 Waste Gas Handling

Exhaust gases from the process are passed through a toxic gas scrubber, before emission well above roof level. Initially, this scrubber was the simple charcoal barrel absorption type which was effective but of insufficient capacity for long term utilisation. This was replaced by a wet scrubber (Mystair) which is fully self-dosing and monitoring, and capable of removing phosphine to below the sensitivity of the MDA gas detector (< 10 ppb) before > 1000:1 dilution in air and fan driven emission well above roof level.

#### C2.4 Plasma Deposition Machine

Partly as a requirement for containing the RF, the plasma

reactor was entirely enclosed within a metal closure, and this cabinet was then air extracted. In addition, the pumping stack was also enclosed and air extracted, partly because of the risk of a vacuum pump explosion when using silane. Maintenance of the rotary pump (e.g. oil change) was performed using a small self-contained breathing set.

The main hazard associated with the reactor chamber was considered to be dust particles (since it is regularly taken down to vacuum), and nose/mouth dust masks were worn as appropriate. All parts were removed to a nearby fume cupboard for cleaning and storage. Since some phosphides are unstable in moist air, back extraction through the chamber was fitted to operate when the chamber was up to air.

#### C2.5 Procedures and Staffing

The safe operation of the equipment relies above all on safe procedures and competent staff. Only fully qualified personnel versed in all the necessary routine and emergency procedures are allowed access to the plasma machines. Working procedures includes the use of gloves for any handling of samples and maintenance work.

### C3 ADDITIONAL PROCEDURES

Experience in handling phosphine prompted these additional procedures:

#### C3.1 Additional Extraction of Chamber Enclosure

An improved extraction facility, to the standard of a conventional fume cupboard, was fitted to the reactor enclosure. This was designed to greatly reduce both gaseous and particle emission from the chamber area.

#### C3.2 Regular Cleaning of Chamber Enclosure

In addition to improved extraction, the reactor enclosure was made as empty as possible to allow effective regular cleaning. A

specialist toxic waste vacuum cleaner was installed, with a HEPA filter and extraction on its exhaust, to vacuum clean the chamber enclosure. Following this the chamber area is wiped over with damp paper cloths which are then disposed of as hazardous waste.

### C3.3 Full Working Breathing Apparatus

Whilst not a safety feature for normal working, a two man, trolley based, self-contained breathing set is being purchased (this has been delayed by the revision of the British Standard covering this equipment). The principal application of this equipment will be on servicing major items (e.g. pumps, vacuum components).

### C3.4 Lightweight Filtered Air Hood

During minor chamber modifications and electrode changes, it is difficult for the operator to work without his head within the chamber enclosure. For this purpose, a powered, filtered air respirator with lightweight hood is used. The power pack and filter are mounted on the user's back, keeping the air intake away from the potentially contaminated area.

### C3.5 Automatic Oil Change

The rotary pump used for this work is an Edwards E2M40 mineral oil pump. Whilst fomblinised pumps are often recommended for handling silane and other hydrides, the improved reliability of mineral oil pumps over fomblinised pumps is of prime importance because of the contamination problem. However, the mineral oil pumps need a regular oil change, which exposes the oil to the cleanroom atmosphere. Consequently, an automatic oil change system has been devised and fitted, which allows removal of the contaminated oil into a sealed container and introduction of new oil without any exposure to the cleanroom atmosphere. Its principle of operation is to entirely isolate the pump and pressurise the casing with nitrogen to force the old oil into a container, and then to extract the pump and pressurise a new oil feeder tank to refill the pump. Fig. C.1 shows a schematic of this system. Isolating the pump involves closing the

exhaust port, so this valve is carefully interlocked so that it cannot close whilst the pump is running, since the pump could otherwise easily blow itself apart.

### C3.6 Exhaust Line Oil Mist Filters

The original specification for the gas scrubber included inlet oil mist filters to trap any oil mist from the rotary pumps. The scrubber manufacturer stated that these were not necessary, and they were not originally fitted. However, experience has shown that oil mist can ultimately be transferred to the outlet of the scrubber, still containing 'unscrubbed' phosphides/phosphine. Fitting proper inlet oil mist filters has removed this problem. It is recommended that oil mist filters are always specified in the purchase of a wet gas scrubber.

### C3.7 Full Washing Facilities Locally

Since phosphine can be detected at very low limits, it was found that, despite using gloves, particles of phosphides could get onto the hands and start decomposing, causing them to smell. Whilst limited washing facilities were already in the laboratory, in addition to nearby toilet facilities, these were substantially upgraded to enable and encourage regular washing.

### C3.8 Disposal Cleanroom Garments

Work which involved significant disassembly of the equipment (e.g. electrode change or chamber cleaning) was found to carry risk of transferring phosphide particles to the operators' cleanroom garments, and even ultimately to their clothes. The latter was particularly of concern, being a significant health hazard and also a potential embarrassment; sweating would cause the unstable phosphide particles to decompose and emit phosphine, giving the operator a distinct odour. In addition to placing extra emphasis on maintaining the cleanliness of the reactor cabinet during such work, and on improving working procedures, it was found advantageous to use a new disposable cleanroom garment (Tyvek coveralls) for each entry into the cleanroom.

### C3.9 Blood Testing

Following receipt of reference [1], staff associated with the programme of developing the super-phosphides were tested for genetic damage, as a precautionary measure additional to the safety measures detailed above. Some difficulty was experienced in finding a laboratory capable of performing the required tests, but they were finally carried out at the Queen Elizabeth Hospital for Children (Hackney Road, London, E2 8PS).

Cultures from the blood samples were established in media designed to reveal chromosome breaks and rearrangements as evidence of chromosome damage. The analysis was performed by G-banding the resulting slides, and by special treatment using DNA antagonists to show the degree of breakage and exchange between sister chromosomes compared with controls.

The results showed no genetic abnormality for any of the workers tested.

This blood testing is not being used routinely in this programme since the approach adopted is to reduce exposure levels to an absolute minimum. Exposure above previous levels would be readily detectable, and the main risk of genetic damage is now considered to be from a major incident rather than continued low exposure.

### C4 CONCLUSIONS

Phosphine is a highly toxic gas which needs to be handled with extreme caution. Its strong odour is a useful safety indicator, but cannot be relied on in an enclosed environment because of olfactory fatigue. By implementing strict safety measure, and enforcing high levels of staff discipline, phosphine can be used with acceptable levels of safety.

Whilst considerable thought went into safety during the initial setting up of the LWIR materials programme, experience of handling phosphine has evolved several further techniques for its safe handling.

## C5 REFERENCES

- 1) V. F. Garry, J. Griffith, T. J. Danzl, R. L. Nelson, E. B. Whorton, L. A. Krueger, J. Cervenka, Science, 13th October 1989, p187.
- 2) R. Wilson, F. H. Lovejoy, R. J. Jaeger, P. L. Landrigan, JAMA (Journal of the American Medical Association) 244(2), 1980, p148.




Figure C.1: Automatic Oil Change System